

Entrance Cabinet Selection Guide











	ULTRA HYPERSCALE EXCHANGE (U-HSX)	MODULAR HYPERSCALE EXCHANGE (M-HSX)	HYPERSCALE EXCHANGE (HSX)	VERITCAL HYPERSCALE EXCHANGE (V-HSX)	VERITCAL HYPERSCALE EXCHANGE (3K-V-HSX)
Part Number	FTHFC-41K-SK1 (Cabinet & Starter Kit)	HDMEC-MX-STV001 (Cabinet & Starter Kit)	HDFOC-X-FRM-STC (Cabinet)	FTHFC-10K-V-SK1 (Cabinet & Starter Kit)	FTHFC-3K-V-SK1 (Cabinet & Starter Kit)
Fiber Capacity	41,472	20,736	20,736	10,368	3,456
Cable Entry Areas	2 = Top; 2 = Bottom 6 = Left; 6 = Right	2 = Top; 2 = Bottom	2 = Top	2 = Top; 2 = Bottom; 2 = Left; 2 = Right	2 = Top; 2 = Bottom; 1 = Left; 1 = Right
Fray Capacity	48 x 864F	48 x 432F, 72 x 288F	72 x 192F, 72 x 288F	24 x 432F	8 x 432F
Max Port	N/A	2,592	N/A	N/A	N/A
Port Type	N/A	LC	N/A	N/A	N/A
Mount	Floor/Wall	Floor	Floor	Wall	Wall
ABF Suitable	×	8	8	×	&
Hyperscale/AI DC Suitable	⊘	②	②	⊘	②
DC/Central Office Suitable	②	②	⊘	⊘	⊘
Mass Transit Suitable	Limited Applications	Limited Applications	Limited Applications	Limited Applications	Limited Applications
QR to Cut Sheet			0 (
	<u>View Cut Sheet</u>	<u>View Cut Sheet</u>	<u>View Cut Sheet</u>	View Cut Sheet	<u>View Cut Sheet</u>

To learn more information visit www.SumitomoElectricLightwave.com