

SUMITOMO RECOMMENDED PROCEDURE

SRP SP-F04-037



INSTALLATION PROCEDURES FOR

STRAIN RELIEF KELLEMS GRIPS

PARA.	CONTENTS
1.0	General
2.0	Safety Precautions
3.0	Reference Documents
4.0	Equipment / Tools Required
5.0	Equipment Layout
6.0	Preparing TDU Enclosure
7.0	Installing Strain Relief Kellems Grip
8.0	Special Procedure for Armored (Dash -1 and Dash -2) Tube Cables

SUMITOMO ELECTRIC LIGHTWAVE CORP. 201 South Rogers Lane, Suite 100, Raleigh, NC 27610 (919) 541-8100 or 1-800-358-7378 www.sumitomoelectriclightwave.com SEL is a Member of the Sumitomo Electric Industries, Ltd. Group Sumitomo Electric Lightwave reserves the right to improve or modify these specifications without notice.

1.0 General

1.1 This procedure describes the standard techniques for installing Strain Relief Kellems[®] Grips to FutureFLEX Air-Blown Fiber (ABF) tube cables in indoor applications only.

1.2 Strain Relief Kellems Grips provide an effective means of securing tube cable ends to indoor TDU entry points. They are <u>not</u> to be used where the TDU is subject to moisture from hosing, splashing, or flooding. Therefore, their use is restricted to indoor applications <u>only</u>.

1.2.1 The wire mesh of the Grip provides tube cable strain relief and prevents kinking of the cable at its entry point.

1.2.2 The wire mesh of the Strain Relief Kellems Grip also aids in protecting the tube cable if the TDU is located in an area susceptible to damage.

Note: Liquid-Tight Kellems Grips are the recommended fittings to seal and secure ABF tube cables to Tube Distribution Units (TDUs) subject to hosing, splashing, or flooding conditions <u>and</u> where positive anchoring of the tube cable ends is required. Refer to Sumitomo Recommended Procedure, Installation Procedures for Liquid-Tight Kellems[®] Grips, SRP SP-F04-024.

2.0 Safety Precautions

2.1 The use of safety equipment (safety glasses, safety shoes, cut-resistant Kevlar gloves) is recommended during this installation procedure.

3.0 Reference Documents

3.1 Sumitomo Recommended Procedure, *FutureFLEX Tube Cable Installation Procedures,* SRP SP-F04-008.

3.2 Sumitomo Recommended Procedure, *FutureFLEX Grounding & Bonding Metallic Tube Cable Procedures,* SRP SP-F04-030.

4.0 Equipment / Tools Required

The following equipment, tools, and materials, are required to complete this procedure:

4.1 **See TABLE 1** for Strain Relief Kellems Grip Part Numbers. Recommended Knockout Hole Sizes are also provided.

4.2 Tube Cable Cutter (BETL03)

4.3 Utility Knife with Hook Blade

- 4.4 10-inch (or larger) Adjustable Wrenches
- 4.5 Hammer
- 4.6 Hole Punch Set for Knockout Holes
- 4.7 Felt Tip Pen / Marker
- 4.8 Tape Measure

5.0 Equipment Layout

5.1 **See Fig. 1** for a typical Strain Relief Kellems Grip layout.

6.0 Preparing TDU Enclosure

6.1 **Refer to TABLE 1** and identify Recommended Knockout Hole size based on the Strain Relief Grip to be used.

TABLE 1 Strain Relief Kellems Grips

ng Indoor able P/N	Use Strain Relief Grip P/N DEDTSR1	Recommended Knockout Hole Size (inches) 1.719 – 1.766
TC02TRC		
TC04TRC	DEDTSR1	1.719 – 1.766
TC07TRC	DEDTSR1	1.719 – 1.766
TC12TRC	DEDTSR2	1.969 – 2.016
TC19TRC	DEDTSR4	2.953 - 3.000
TC24TRC	DEDTSR6	3.000 - 3.045
TC02TRC-1	DEDTSR1	1.719 – 1.766
TC04TRC-1	DEDTSR1	1.719 – 1.766
TC07TRC-1	DEDTSR2	1.969 – 2.016
TC12TRC-1	DEDTSR4	2.953 - 3.000
TC19TRC-1	DEDTSR5	2.953 - 3.000
g Outdoor able P/N	Use Strain Relief Grip P/N	Recommended Knockout Hole Size (inches)
TC02MSOS	DEDTSR1	1.719 – 1.766
TC04MSOS	DEDTSR1	1.719 – 1.766
TC07MSOS	DEDTSR1	1.719 – 1.766
TC12MSOS	DEDTSR	2.953 - 3.000
TC19MSOS	DEDTSR4	2.953 – 3.000
	DEDTSR6	3.000 - 3.045
		1.719 – 1.766
		1.969 - 2.016
		2.453 - 2.500
100/10003-2	DEDTSR3 DEDTSR4	2.453 - 2.500
	able P/N TC02TRC TC04TRC TC07TRC TC12TRC TC19TRC TC24TRC TC02TRC-1 TC04TRC-1 TC07TRC-1 TC12TRC-1 TC19TRC-1 g Outdoor able P/N TC02MSOS TC04MSOS TC07MSOS TC07MSOS	Able P/NOse Strain Relief Grip P/NTC02TRCDEDTSR1TC04TRCDEDTSR1TC07TRCDEDTSR2TC12TRCDEDTSR4TC24TRCDEDTSR6TC02TRC-1DEDTSR1TC04TRC-1DEDTSR1TC07TRC-1DEDTSR2TC12TRC-1DEDTSR4TC07TRC-1DEDTSR4TC19TRC-1DEDTSR4TC19TRC-1DEDTSR4TC19TRC-1DEDTSR5g Outdoor able P/NDEDTSR1TC02MSOSDEDTSR1TC07MSOSDEDTSR1TC12MSOSDEDTSR1TC19MSOSDEDTSR4DEDTSR6DEDTSR6TC02MSOS-2DEDTSR1TC04MSOS-2DEDTSR2

Notes:

• Based on installation application, if Armored tube cables (Dash -1 or Dash -2) are to enter an enclosure from the top or sides, select the Strain Relief Grip P/N based on the Dash -1 or Dash -2 P/Ns given above.

• Based on installation application, if Armored tube cables are to enter an enclosure from the bottom, the Strain Relief Grip is to be installed on the inner core cable and the outer armoring is to be secured separately with standard clamps or other suitable fasteners. Select the Strain Relief Grip P/N based on the core cable P/N. See Para. 8.0 for the special procedures required for installing Strain Relief Kellems Grips on Armored (Dash -1 and Dash -2) Tube Cables installed in a vertical orientation.




Figure 1 Strain Relief Kellems Grip Layout

6.2 Prepare TDU enclosure by selecting and marking tube cable entry point locations. To best optimize TDU capacity, it is recommended to stagger tube cable entry locations if possible. **See Fig. 2a and Fig. 2b.**

6.3 Use appropriate size hole punch and create opening in TDU.




Figure 2a Inline Tube Cable Entry Locations Acceptable but Fails to Optimize TDU Capacity




Figure 2b Staggered Tube Cable Entry Locations Preferred Method to Optimize TDU Capacity

7.0 Installing Strain Relief Kellems Grip

7.1 After the appropriate size knockout hole is cut into the TDU enclosure, compress wire mesh and slide Grip onto end of tube cable.

7.2 Insert tube cable and threaded end of Grip into entry hole.

7.3 Slide Locknut over tube cable end and thread onto Grip. Only hand-tighten at this time.

7.4 Compress wire mesh and adjust tube cable length inside TDU as required.

7.5 When tube cable length is adjusted, mark tube cable jacket in preparation for stripping.

7.5.1 Make first mark about 1" beyond threaded end of Grip body. See Fig. 3.

7.5.2 Second mark must be determined on-site. Measure distance required to route individual tubes from the 1" mark to the farthest tube connection point inside TDU and make second mark.

7.6 Remove Locknut, Grip, and tube cable from TDU. Compress wire mesh and remove Grip from tube cable.




Figure 3 Measuring and Marking Tube Cable

7.7 Use Tube Cable Cutter (BETL03) to cut tube cable at second mark.

7.8 Use Hook Blade Knife to lightly score tube cable jacket at 1" mark. Pull ripcord and strip jacket away to expose individual tubes.

7.9 Compress wire mesh and slide Grip over ends of tubes / tube cable. Adjust tube cable position until there is about 1" of tube cable jacket exposed beyond threaded end of Grip.

7.10 Insert tubes / tube cable and threaded end of Grip into entry hole. Make final adjustments to tube cable length inside TDU as required.

7.11 Slide Locknut over end of tubes / tube cable and thread onto Grip. Wrench-tighten Locknut at this time.

7.12 Slide plastic Insulated Bushing over end of tubes / tube cable, thread onto Grip, and firmly hand-tighten only. **See Fig. 4.**

7.13 Remove any slack from installed wire mesh by smoothing it tight to tube cable to complete the Strain Relief Kellems Grip installation.




Figure 4 Strain Relief Kellems Grip Installed and Tube Cable Ready for Coupling

8.0 Special Procedure for Armored (Dash -1 and Dash -2) Tube Cables

8.1 The following procedures describe the special techniques required to install Strain Relief Kellems[®] Grips on Armored (Dash -1 and Dash -2) tube cables if they enter an enclosure from the bottom. The Grips are to be installed on the inner core cable and the outer armoring is to be secured separately with standard clamps or other suitable fasteners.

8.2 Armored tube cables employ a spiralwrapped Interlocked Galvanized Steel wrap surrounding a core cable to provide an extremely rugged, high crush resistance tube cable design and is available in two (2) configurations.

8.2.1 Dash -1 tube cable Part Numbers identify a tube cable with a ruggedized Interlocked Galvanized Steel wrap <u>without</u> a Polyethylene (PE) outer jacket. The Dash -1 designs are typically used in indoor applications with General Purpose-, Riser-, or Plenum-rated tube cables. **See Fig. 5.**



Figure 5 A Dash -1 Plenum-Rated Tube Cable (TC07TP2-1 Shown)

8.2.2 Dash -2 tube cable Part Numbers identify a tube cable with a ruggedized Interlocked Galvanized Steel wrap with a Polyethylene (PE) outer jacket. The Dash -2 designs are typically used in outdoor applications with all Dielectric and Metallic tube cable designs. **See Fig. 6.**



Figure 6 A Dash -2 Outdoor Tube Cable (TC07TOX-2 Shown)

8.3 In both configurations (Dash -1 and Dash -2), the ID of the spiral-wrapped Interlocked Galvanized Steel is slightly larger than the OD of the core tube cable. This results in a somewhat "loose fit" between the armor and core cable and allows the core cable to move if, for example, subjected to thermal expansions / contractions.

8.4 The special technique for securing Dash -1 and Dash-2 armored tube cables to indoor TDUs with Strain Relief Kellems[®] Grips is that: 1) the Strain Relief Grip is installed on the inner core cable and 2) the outer armoring is secured separately with standard clamps or other suitable fasteners.

8.5 Prepare the tube cable for installation by first removing / unraveling the Interlock Galvanized Steel wrapping back to about 2"-3" longer than the wire basket of the selected Strain Relief Grip. Bend the steel wrap back and forth until it breaks and remove it from around the core cable. These steps expose a length of core cable beyond the armor. **See Fig. 7.**

8.6 Install the Strain Relief Grip onto the core cable and complete the installation as previously described.

8.7 Secure the outer armoring of the tube cable with any suitable clamp or similar fastening hardware.

8.8 Ground & Bond the metallic elements of the armored tube cable. Refer to Sumitomo Recommended Procedure *FutureFLEX Grounding & Bonding Metallic Tube Cable Procedures,* SRP SP-F04-030.




Figure 7 Strain Relief Grip Securing Armored Tube Cables (Armored Riser Tube Cable Shown)